



## WARNINGS

- 1 Read the warnings and instructions in the manual before using your pistol
- 2 Learn about the carring guns laws in your residence country
- **3** In case of neglection concernining the instructions there might be many unpleasant results
- 4 If you have no experience in using gun ask for help from a specialist
- 5 In order not to turn the gun harmful keep it away from people, animals because any incident or accident caused by the gun the place around it also gets damage. Do not understimate the usage instructions.
- 6 Hide the bullets in a way that no children will have access to them
- 7 Always hold the gun assuming that it's fully loaded
- 8 Do never jocke or play around with a gun (pistol). Behave yourselves when it comes to guns and any explusives (the devil does not load the gun but human does and he forgets)
- 9 Apart from the shooting moment do not keep your finger on the triger. And don't pull the triger before poiting the barrel to the target.
- 10 Before firing or pulling the triger make sure there are no babies, animals or anyone who might not be happy with the noise or you will be charged quilty instead for that.

- 11 Your firing position should be straight and stretched arm position and should be above the eye level (Picture 2) or upwards straight and stretched position above the head and ears level (Picture 1) do not ever fire near to your body not head (Picture 3)
- 12 You might face some hearing problems due to it's loud noise
- 13 Due to the gases and explusive substances spread from the gun it might cause dangerous and harmful results, choose a closed and non AC area to perform your shooting.
- 14 Gathering and delivering the case to the dustbin is a healthful environment care gesture.
- 15 This gun was not design to cause any throwing of a part or substance from it's barrel. Any problem apart from the usage of the gun the manufacture shall take the responsabilty.
- 16 The material used in product are not the same with the ones used for real guns. So if any change you did try to use as real will demage on your self and the people arround you
- 17 The right to make any change or improve anything on the gun belongs to the manufacturer







(Picture 2)

(Picture 3)



## **SAFETY (hummer safety)**

In the Picture 4 as it shows when the safety (triger) is pressed the hummer safety goes downwards and to fire it has to be pulled upwards.

### LOADING THE BULLETS AND USAGE

Place your finger on the cherger and (Picture 5) and hold it from the lower part and remove.(for 9.cal Load 15 round) load the charger with the bullets(6) and push it until you hear confirmation Tik sound.

In order to drive the bullets to the barrel pull it completely and leave it (Picture 7) from now on you are ready to fire. And just pulling the triger is enough to fire. For each bullet you should pull the triger once (semi auto's nature)

When the bullets finish the sleeve will remain opened and letting you know that it's empty. (Picture 8) and you can bring the sleeve bar to the old position just by pressing the signal aside of it (Picture 9)



■ www.aksaarms.com



## **REMOVE / SETTINGS**

- Picture 5 press the buton showed and remove the charger
- Picture 12 pull the part slightly and level line it up with the hull. 13-as showed in the Picture push the part on the hull and remove it from the hull.
- •14 pull the part as shown in the Picture and hold it upwards. 15 as shown in the Picture 15 first pull back and then take up the mecanism and the part is ready to be cleaned.
- 16 In order to remove more parts more than shown in the Picture 16 you'll need some hand equipments. And while removing the parts there might be few damages on your hands and also the parts might get lost so putting all this together the manufacturers do not addive to remove the many parts of the pistol.
- 17 and to reset the gun or put the parts together you just have to do all the steps on contary.



04



#### **MAINTENANCE**

- . Keep your pistols away from acid, wet and powdery anvironment
- After firing specially oil the lean part of the barrel where the bullets strike
- After cleaning the hul, charger and all the working parts oil them.
- Do not leave the charger loaded with bullets when not using
- In case the pistol stop working try another manufacture's cartridge

And if it does not work also then take it back to the manufacture and do not use a high volume(barli) of cartridge for shooting.

# ► K SERIES CAL. 9 mm P.A. TECHNICAL SPECIFICATIONS

MAGAZINE CAPACITY	14+1 Pcs
LENGTH	180 mm
HEIGTH	130 mm
WIDTH	36 mm
BARREL LENGTH	100 mm
EMPTY WEIGHT	675 g
CALIBER	9 mm P.A.
FULL MAGAZINE WEIGHT	180 g

vww.aksaarms.com 05



# AKSA BLANK FIRING GUN 9 MM. P.A.



-06



# ► AKSA BLANK FIRING GUN 9 MM. P.A.



www.aksaarms.com 07

AKSA SİLAH

Contact

Phone:+90 (530) 771 68 81 E-Mail:export@aksaarms.com

Web :www.aksaarms.com

ADRESS Üzümlü Mah. Alparslan Türkeş Cad. No: 26 Beyşehir / KONYA/TURKEY